

Quick Guide: Care for Painted Wood

Protection

- Try to protect the product from rainfall if possible. It also helps to position the furniture so that water can run off during parts of the day if they cannot be completely protected.
- Wipe off the furniture after rain showers to remove any standing water.
- If possible, winter storage under cover or in, for example, a shed will help extend the longevity of the product.

Cleaning

- Ensure the products are kept clean and be observant for stains. Use soap, water, and a clean cloth or sponge. A coarser sponge can be used if the furniture is very dirty.
- If mould has appeared on the product, use Grovrent or Trallrent, or stronger agents like Alg- and Møgelfritt depending on the severity of the mould infestation.
- Rinse thoroughly with water to remove any cleaning agents. Avoid cleaning with a high-pressure washer that can damage the paint and penetrate moisture into the wood.

Touch-Up Painting

- Ensure regular maintenance painting, preferably once a year.
- If there are damages to the paint, the wood can absorb moisture and cracks may occur. This can also cause the wood to rot from the inside. In case of damage, sand the surface clean with sandpaper and apply a new coat of paint.
- Ask us which paint is suitable for your product.