


ASSEMBLY INSTRUCTIONS

nola

Headoffice: Nola Industrier AB Repslagargatan 15b Box 17701
 S-118 93 Stockholm T:+46(0)8 702 19 60 F:+46(0)8 702 19 62
 E:headoffice@nola.se Sales/showroom: Skeppsbron 3
 S-211 20 Malmö T:+46(0)40 17 11 90 Orderfax:+46(0)40 12 75 45

www.nola.se



Specification/

Ö13-54 Frame, waste paper basket 120L
 Ö13-54A Frame, ashtray for waste paper basket
 120L Ö13-55 Frame, waste paper basket 240L

Delivery specification/


Ö13-54	
Waste paper basket 120L	1 pc.
Base	1 pc.
Screw M10	4 pcs.
Ö13-54A + Ö13-54 (supplied assembled)	
Waste paper basket 120L with ashtray	1 pc.
Base	1 pc.
Screw M10	4 pcs.
Ö13-54A	
Ashtray for waste paper basket 120L	1 pc.
Spacers	4 pcs.
Screw and nuts M8	4 pcs.
Ö13-55	
Waste paper basket 240L	1 pc.
Base	1 pc.
Screw M10	4 pcs.

ASSEMBLY INSTRUCTIONS





Headoffice: Nola Industrier AB Repslagargatan 15b Box 17701
S-118 93 Stockholm T:+46(0)8 702 19 60 F:+46(0)8 702 19 62
E:headoffice@nola.se Sales/showroom: Skeppsbron 3
S-211 20 Malmö T:+46(0)40 17 11 90 Orderfax:+46(0)40 12 75 45


www.nola.se



Frame waste paper basket
240L (Ö13-55)



Frame waste paper basket
120L (Ö13-54)



ASSEMBLY INSTRUCTIONS


nola

Headoffice: Nola Industrier AB Repslagargatan 15b Box 17701
S-118 93 Stockholm T:+46(0)8 702 19 60 F:+46(0)8 702 19 62
E:headoffice@nola.se Sales/showroom: Skeppsbron 3
S-211 20 Malmö T:+46(0)40 17 11 90 Orderfax:+46(0)40 12 75 45

www.nola.se



Frame waste paper basket 120L with ashtray (Ö13-54A + Ö13-54)



ASSEMBLY INSTRUCTIONS




Headoffice: Nola Industrier AB Repslagargatan 15b Box 17701
 S-118 93 Stockholm T:+46(0)8 702 19 60 F:+46(0)8 702 19 62
 E:headoffice@nola.se Sales/showroom: Skeppsbron 3
 S-211 20 Malmö T:+46(0)40 17 11 90 Orderfax:+46(0)40 12 75 45

www.nola.se



Ashtray for Frame waste paper basket 120L
 (Ö13-54A)



Replacement of ashtray /

If you have purchased an ashtray for an existing bin, you must install the product.


For assembly.

- 1) Place the ashtray on top of the waste paper basket, with the opening on the same side as the door.
- 2) Open the lid on the ashtray, mark out holes.
- 3) Lift the ashtray away from the waste paper basket and drill into the markings with a 9mm drill.
- 4) The ashtray can then be mounted with M8 and distance as follows.
- 5) Make sure the ashtray is centred and tightened properly.

Emptying/

- 1) Lift the cover, make sure the butt collector is not glowing
- 2) Lift out the butt collector and drain
- 3) Replace the butt collector and close the lid





Assembly/

- 1) The base is first fixed into the ground with M12 fasteners, which are chosen depending on the surface, as described below. (Screws not included)
- 2) The waste paper basket can then be attached to the base with the included M10 screw.

Assembly on wood flooring /

Fix with a French wood screw on wood flooring

Assembly on small cobbles or street surfaces /

Underlay cobbles with concrete. There may not be any sand between the cobbles and the concrete. Drill the paving for expanders or chemical anchors. Assembly using expander provides a removeable attachment. Assembly with chemical anchors provides a permanent attachment.

Assembly on concrete surfaces /

Drill the concrete for expander or chemical anchors. Assembly using expander provides a removeable attachment.

Assembly on gravel or grass /

Excavate the ground to install a concrete foundation. Cast a foundation in concrete pipes or cardboard pipes. The top of the foundation must end with a radius. Drill the foundation for expander or chemical anchors. Attach the foot to the foundation and restore the ground.

Care and Maintenance /

Please refer to separate document on care and maintenance.

